



## PURE PATH



### IDEA SUBMISSION

If you have an idea for a new and innovative sports training product, visit SKLZ.com to submit your concept. Some restrictions may apply.

### LIMITED WARRANTY

REGISTER YOUR PRODUCT AT SKLZ.COM TO ENSURE WARRANTY COVERAGE, GET NEW PRODUCT INFORMATION AND SPECIAL DEALS FROM SKLZ

Pro Performance Sports (PPS) / SKLZ warrants to the original consumer purchaser of any PPS/SKLZ product it manufactures that the product will be free of defects in materials or workmanship for 90 days (unless specified in alternate warranties) from the date of purchase. If defective and purchased from a retail store, return the product along with receipt to the retail store where the product was purchased. If the item was purchased from PPS/SKLZ, return the product along with the packing slip (proof of purchase) postage prepaid to the address below for replacement consideration. Label: Attn: Returns

This warranty does not cover damages resulting from accident, misuse, abuse or lost merchandise. Only valid in the USA. All returns sent to PPS/SKLZ require a Return Merchandise Authorization number (RMA). For returns to PPS/SKLZ and for all other Customer Service inquiries, please email customerservice@sklz.com or call toll free, 1-877-225-7275 for a return authorization number for any exchange.

Made in Taiwan. ©2012 Pro Performance Sports, LLC. All rights reserved. Manufactured and distributed by SKLZ/Pro Performance Sports: 2081 Faraday Avenue, Carlsbad, CA 92008 U.S.A. SKLZ, SKLZ Pro Grade, SKLZ Chrome and Sport-Brella are registered trademarks of Pro Performance Sports, LLC, its subsidiaries and affiliates. Product features, appearance, and specifications may be subject to change without notice. Unauthorized duplication is a violation of applicable local and international laws.

### INSTRUCTION MANUAL

Thank you for choosing SKLZ PURE PATH. We are dedicated to providing you with the best tools and instruction possible to help you unleash your athletic potential. If there is anything else we can do to help you optimize your workouts, send us an email (customerservice@sklz.com) or give us a call (1-877-225-7275).

#### BEFORE YOU BEGIN:

- » Read all setup and usage instructions carefully.
- » Recommended for athletes over 14 years old. Athletes under 18 years of age should use only under strict adult supervision.
- » Always check equipment for wear or damage before use. If any is found, do not use product.
- » Make sure you have all the PURE PATH components. Please contact SKLZ customer service if you're missing anything.

#### CARE INSTRUCTIONS:

- » Hand wash with vinegar and water.

#### ⚠ CAUTION:


Only use the Pure Path in open areas where you wouldn't be hitting toward any people, animals, or objects. Never swing a golf club when anyone is in front of or behind you.

VISIT SKLZ.COM FOR  
INSTRUCTIONAL VIDEO AND CONTENT



Training Videos & Articles: SKLZ.com  
facebook.com/SKLZgolf  
twitter.com/golfSKLZ

### PURE PATH PARTS:



A


ARM ASSEMBLY

B

GROUND STAKE


SKLZ.COM

## ASSEMBLY




### STEP 1

Connect by inserting the arm assembly into the ground stake. Select the desired height of the arm assembly by using the push button adjustments.




### STEP 2

Once the arm assembly is at the desired height, secure it in place by tightening the black knob.



### STEP 3

Push assembled Pure Path into the ground until the stake is fully inserted.




### STEP 4

For the desired height, make sure the ball hangs straight down from the arm assembly and spins freely. It should never rest on the ground or you will not be able to observe how the ball rotates.

## USAGE INSTRUCTION

The Pure Path is a very simple and effective training tool to help golfers learn to hit "pure" shots consistently. By observing the direct result of your ball striking, you can work on making the necessary adjustments to create a swing path that results in balls that fly straight on the golf course.




### STEP 1 - SETUP

Position your club behind the ball, keeping the arm perpendicular to your body and "target" line.

If you're hitting an iron or wedge, the ball should be just above the ground and the push button should be set on the lowest hole.

If you're hitting a wood or driver, the ball should be positioned such that 1/2 to 1/3 of it stays above the top of your club. The push button should be set on the middle or top hole.



### STEP 2 - FEEDBACK

Take your normal swing, and then observe the path the ball takes as it spins. The ball will reset itself in position for your next swing.

### STEP 3 - ADJUSTMENT

If you observe the ball moving too far left or right, you can work on changing your swing path into the ball to straighten out your shot. Once you start hitting the ball consistently straight, the Pure Path will groove this feel into your normal swing.

**▲ WARNING** Only use the Pure Path in open areas where you wouldn't be hitting toward any people, animals, or objects. Never swing a golf club when anyone is in front of or behind you.